



Spread Lavatory Fittings

Standard Trim — RE-NU

Plumbing Parts Depot
800-448-8977 www.ppd1.biz

Limited Parts
Available



no.	description	part no.	B 708-9	B 708-9A	B 714 B 715	B 714 A B 715 A
1	Button - Specify Index	1255-12				
2	Handle Screw	264-17				
3	Handle	1186-12				
4	Escutcheon	1256-22				
5	Escutcheon Nipple	39994-05				
6	Stuffing Nut	1184-17				
7	Stem Packing	1311-07				
8	Stuffing Box	36663-08				
9	Stuffing Box Washer	73-07				
10	Brass Washer	1167-17				
11	Stem w/washer & Screw - Hot or Cold - R.H. Thread	21186-02				
12	Seat Washer	441-07				
13	Seat Washer Screw	159-17				
14	Re-Nu Sleeve - Hot or Cold - R.H. Thread	20336-08				
15	Valve Lock Nut	24526-08				
16	Iron Washer	1519-08				
17	Valve Body	36751-08				
18	Coupling	95-15				
19	Coupling Nut	24220-08				
20	Slip Joint Washer	1010-17				
21	Friction Washer	21391-08				
22	Slip Joint Nut	1231-27				
23	Supply Tube	41497-08				
24	Lift Knob	1189-12				
25	Lift Rod - 11 7/8" Long	39799-02				
26	Spout Cap	19155-02				
	Spout Cap	19408-02				
	Spout Cap	36360-02				
27	3 3/4" Spout w/shank	22224-02				
	3 3/4" Spout w/shank	22226-02				
	3 3/4" Spout w/shank	8170-02				
	3 3/4" Spout w/shank	8173-02				
	4 3/4" Spout w/shank	22223-02				
	4 3/4" Spout w/shank	22225-02				
	4 3/4" Spout w/shank	8167-02				
	4 3/4" Spout w/shank	8175-02				
28	Stream Regulator	33953-08				
29	Aerator Adapter	168-25				
30	Aerator	56117-02				
31	Spout Lock Nut	24590-08				
32	Slip Joint Nut	24748-08				
33	Slip Joint Washer	396-07				
34	Supply Tee	20187-08				
	Supply Tee	20177-08				
35	Spout Tube	41116-08				
36	Sleeve for Chain	275-02				
37	Chainstay Nut	28182-02				
38	Bead Chain	1112-02				
39	Link	1128-22				
40	Rubber Stopper	1012-12				
41	Handle Assembly - Specify Index	9171-02				
42	Chain & Stopper S/A	8174-02				
43	Re-Nu Unit S/A	18625-02				
44	Stuffing Box S/A	8138-08				
45	Lift Knob & Rod S/A	13722-02				
Sub-assemblies						
Supply Tee S/A (Parts 20 thru 23, 32-33-34)		16581-08				
Supply Tee S/A (Parts 23-32-33-34)		16583-08				
Valve S/A (Parts 5 thru 22)		15394-02				
Spout S/A - B-708 only (Parts 26-27-28-31-35)		13719-02				
Spout S/A - B-709 only (Parts 26-27-28-21-35)		13720-02				
Spout S/A - B-708-A only (Parts 27-29-30-31-35)		4873-02				
Spout S/A - B-709-A only (Parts 27-29-30-31-35)		4883-02				
Spout S/A - B-714 only (Parts 26-27-28-31-36 thru 40)		18565-02				
Spout S/A - B-715 only (Parts 26-27-28-31-36 thru 40)		18566-02				
Spout S/A - B-714-A only (Parts 26-27-29-30-31-36 thru 40)		4872-02				
Spout S/A - B-715-A only (Parts 26-27-29-30-31-36 thru 40)		4882-02				

Note - For Pop-up Drain parts refer to B 767 on page 156
For Chain & Stopper Drain parts refer to R 2522-1 1/4" on page 154